CURRENT

MODEL G2 Dual Zone Electric Grill



SCAN HERE FOR EASY ASSEMBLY WITH

BILT.

INSTALLER/ASSEMBLER:

Leave this manual with consumer.

CONSUMER:

Keep this manual for future reference.

This instruction manual contains important information necessary for the safe use of the appliance.

Follow all warnings and instructions when using the appliance.

SAFETY SYMBOLS

The symbols and boxes shown below explain what each heading means. Read and follow all of the messages found throughout the manual.

CAUTION

CAUTION: Indicates a potentially hazardous situation or unsafe practice which, if not avoided, may result in minor or moderate injury.

WARNING

WARNING: Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

DANGER

DANGER: Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

READ ALL INSTRUCTIONS

For Safe Use of Your appliance and to Avoid Serious Injury:

WARNING

Failure to follow all manufacturer's instructions could result in serious personal injury and/or property damage.

- Read and follow all the information and safeguards in this product guide before attempting to assemble or operate this grill.
- Keep appliance area clear and free from combustible materials, gasoline and other flammable vapors and liquids. Do not use or store gasoline, kerosene or other flammable liquids within 20 feet of this grill when in use.

CAUTION

For outdoor household use only. Do not use indoors or for commercial cooking.

- It is the responsibility of the assembler/owner to assemble, install and maintain grill.
- Fuel, such as charcoal briquettes, is not to be used with appliance. The grill is not designed for charcoal. The fire will create an unsafe condition and damage the grill.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

DANGER

To protect against electrical shock, do not immerse cord, plugs, controller or heating element in water or any other liquid.

- To prevent grill from being splashed or falling into water, do not use grill within 10 feet of a pool, pond or other body of water.
- Keep electric plugs off ground and dry. Store grill in weather protected area or under grill cover when not in use.
- Use only on properly grounded outlet. Never remove grounding plug or use with an adapter to two prongs.
- Do not let cord touch hot surfaces. Do not let cord hang over edge of tabletop or other items where it can be pulled by children or tripped over.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- **Minimum requirements:** 15A breaker and a 15A GFCI outlet with no other appliances running on the same circuit.
- Running on a lower current outlet/circuit breaker will cause the circuit to trip.

Since 1971 the National Electric Code (NEC) has required Ground Fault Interrupter devices on all outdoor circuits.

- If your residence was built before 1971, check with a qualified electrician to determine if a Ground Fault Interrupter protector exists.
- Do not use this appliance if the circuit does not have GFI protection.
- Do not plug this appliance into an indoor circuit.
- Press the GFCI TEST button (then RESET button) every month to assure proper operation.

To prevent power loss:

- Unplug any other electrical devices, like patio lights, powered by the exterior outlet/circuit breaker before plugging in your grill.

If power is lost during use:

- Identify and unplug any other electrical devices that lost power at the same time and reset the breaker.
    - If your circuit breaker continues to trip during use, consult a qualified electrician.
- Try using a different outdoor electrical outlet, if available.

Extension Cord Use and Safety

For best grill performance use of extension cord is not recommended. If you must use an extension cord, for your safety, care shall be exercised in the use of extension cord:

Use only outdoor type with 3 prong grounding plug, rated for 15 amperes or more, approved by UL, marked with a W and a tag stating "Suitable for Use with Outdoor Appliance".

The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.


The connection to an extension cord should be kept dry and off the ground.

Use the shortest length extension cord required. Do not connect 2 or more extension cords together. A 12 gauge extension cord of 25 ft. or less is acceptable.

USE AND CARE

WARNING

- Do not use 16 or 18 gauge extension cords. Damage to household wiring and/or fire could result.
- Use care when operating your grill.
- Close supervision is necessary when any appliance is used by or near children. Keep children away from grill both when hot and cold.
- Keep pets away from the appliance at all times.
- This appliance is not intended for and should never be used as a heater.
- Use appliance only in well-ventilated space. Keep grill 24" (2 feet) away from walls and rails.
- Do not move the appliance when in use.
- The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to properly assemble or safely operate the appliance.
- When cooking, the appliance must be on a level, stable surface in an area clear of combustible material.
- Do not touch hot surfaces. This appliance will be hot during and after use. Use insulated oven mitts or gloves and long-handled barbecue utensils for protection from hot surfaces or splatter from cooking liquids. Use handles and knobs provided for operation.



DANGER

In case of fire turn controller to OFF position, unplug grill from outlet and allow fire to burn out. Do not use water to put out a fire in this or another electrical appliance.

CAUTION

- Do not leave appliance unattended when ON or while burning off food residue. If appliance has not been regularly cleaned, a grease fire can occur that may damage the product.
- Putting out grease fires by closing the lid is not possible. This appliance is well ventilated for safety reasons.

- Do not use appliance for other than intended use.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn controller "off", then remove plug from wall outlet. Unplug from outlet when not in use and before moving or cleaning. Allow to cool before putting on or taking off parts.

CAUTION

Replace damaged part(s) only with Current Backyard replacement parts. Do not attempt to repair damaged parts.

APARTMENT DWELLERS

- Check with management to learn the requirements and fire codes for using an electric grill in your apartment complex. Use only as allowed.

SAVE THESE INSTRUCTIONS

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

USE AND CARE

Before first use of grill:
- Remove all packaging and sale labels from the grill. Do not use sharp tools to remove stickers.
- Wash cooking grate with warm soapy water, rinse and dry thoroughly.

Before each use of grill:
- Use grill only on a firm and level surface to prevent tipping over.
- To prevent household circuit breakers from tripping, keep electric controller dry and do not use other electrical products on the same circuit.
- Check grease tray to make sure it is empty and is mounted under the drain hole.
    - The grease tray must be inserted into appliance and emptied after each use.
- For stick-free cooking, apply a thorough coating of vegetable oil or vegetable oil based spray to the cooking grate.

Turn grill on:
- Plug power supply cord into a properly grounded, GFI protected outlet. If extension cord must be used refer to "Extension Cord Use and Safety" on page 2.
- Press power button to turn on controller. Light ring will turn blue indicating controller is ready for use.
- Rotating control knob will adjust temperature 5°F up or down. Press knob to confirm desired temperature.
- Light ring will pulse red until **SET** temperature is reached, then will glow solid red. Temperature display will alternate between **SET** and **ACTUAL** temperature until **SET** temperature is reached.
- To adjust temperature, turn clockwise to raise the temperature or counterclockwise to lower the temperature. Press the control knob to **SET** the **DESIRED** temperature.
- For further instruction on controller use, see "Quick Start" on page 5.
- To convert to °C, press Timer and Smart Clean buttons together. Changing between °F and °C can only be done while unit is **"ON".**

Grilling:
- For best results, cook with the lid closed to hold in heat and provide complete cooking.
- Temperature display on the controller indicates the cooking temperature inside the grill.
- Controller setting for various foods are dependent upon outdoor conditions and personal cooking preferences.
- If you have an appliance problem see the "Troubleshooting Section".

Turn grill off:
- To turn controller/grill off, press and hold the power button for 3 seconds until the display turns off.
- Unplug cord from outlet.

Cleaning electrical controller:
- Clean controller face by wiping with a soft, dry cloth.

Controlling grease fires:
- To aid in controlling grease fires use the following precautions:
- Keep grill free from grease; chance of fire is greatly increased by grease buildup.
- Trim excess fat off meat and use less fatty cuts of meat to reduce chance of grease fires.
- If flare-up occurs during cooking reduce controller setting and close lid.
- If flare-up continues turn off the grill and unplug the power cord.

CAUTION

- Do not use sharp or pointed tools to clean grill.
- Do not use abrasive oven cleaners, steel wool or metal brushes to clean grates or grill body. They will damage the finish.

DANGER

To avoid the possibility of burns be sure grill is cool before cleaning.


Cleaning your grill:
- Allow grill to cool before moving, cleaning or storing.
- Do not clean this product with a water spray or the like.
- Excess build up of burned grease and food particles will reduce the grill's cooking performance. To obtain optimum performance:
    - Clean the heating element tray plate assembly and frame at least once a season, more often with heavy use.
    - Using a mild detergent or hot soapy water, moderately scrub surface of the heating element tray assembly with a plastic or brass bristle brush.
    - Clean cooking grates regularly with warm soapy water or a baking soda and water solution. Use non-abrasive scouring powder for stubborn stains.
- Your Current cooking grates are made from anodized aluminum, and will take on seasoning over time. They should get darker and eventually turn black. This is intended, and can help improve the performance of the product.
- Clean the heating element tray assembly under the heating element at least once a season, more often with heavy use.

SAFETY TIPS
- If a bristle brush is used to clean any of the grill cooking surfaces, ensure no loose bristles remain on cooking surfaces prior to grilling. It is not recommended to clean cooking surfaces while grill is hot. Do not clean the cooking grate with a scraper, sharp tool or putty knife.
- It is not recommended to clean the cooking grates in a dishwasher.

Storing your grill:
- Clean cooking grate.
- Store grill in weather protected area or under grill cover when not in use.
- Always unplug your grill prior to storage.

Tools Required for Assembly


Phillips Screwdriver (Included)



Adjustable Wrench (or 7/16" combo wrench) (Not included)



QUICK START



POWER ON / OFF Press the power button to turn the grill on. Press and hold the power button for three seconds to turn the grill off.



SET TEMPERATURE Both temperature zones are initially synchronized. Move the control knob clockwise to set a higher temperature. Press the knob and wait until the light ring stops pulsating, indicating target temperature is reached.. The display alternates between the current and the desired temperature, "Set" and "Act'' flash. Turning counterclockwise decreases the temperature



SEPARATE ZONES To set the zones individually, press the grill symbol above the temperature display on the selected side. This allows the temperature to be set for the selected zone.



SYNCHRONIZE ZONES To synchronize the zones again, rotate the control knob to desired temperature and press the knob to confirm.



TURNING ZONES ON AND OFF

A long press on a grill symbol switches the respective zone off completely. To switch to on again, press the symbol until it lights up again.



TIMER & FOOD TEMPERATURE

Pressing the stopwatch symbol activates the timer. The display flashes 00:00. Use the rotary knob to set the time in 30-second increments and confirm by pressing.
The LEDs for the food temperature sensors are also located on the left. They show the temperatures as soon as they are connected to the grill.



SMART CLEAN


With the lid closed, press the Smart Clean symbol for two seconds until the light ring lights up. Press the knob to start. The grill switches off automatically as soon as the program is completed. To interrupt the process, press the Smart Clean symbol for two seconds and the grill returns to the last setting.



ERRORS

Clear error by pressing control knob or unplugging your grill. If the error persists, please contact our Current Backyard VIP Concierge Team at 1-866-Current or chat with us at currentbackyard.com for assistance.

HARDWARE

KEY	DESCRIPTION	IMAGE	QTY
A	Screw, Machine, 1/4"–20 X 2.75" , Combo Pan Head, Black Dachromat		2
B	1/4–20 Flange Nut Black Dachromat		2
C	Axle,10mm X 9.3mm		2
D	Hitch Pin		2
E	Aluminum Washer 20mm X 11mm		2
F	Aluminum Washer 14mm X 7.4mm		2
G	Machine Srew,M4 X 10mm		10
H	Shoulder Screw		4
J	Screw Machine,Combo Pan Head #1/4–20 X 1/2"		4
K *	Wing Screw,#10–24 X 1/2"		1
L *	Screw Machine,Flat Head #10–24 X 1/2"		2

*** ONLY USED WITH OPTIONAL CABINET KIT (SOLD SEPARATELY)**


REPLACEMENT PARTS LIST

Key	Qty	Description
1	1	LOGO PLATE F/LID
2	1	TOP LID
3	2	TOP LID RUBBER BUMPER
4	1	HANDLE F/ LID
5	2	TOP LID HINGE
6	1	GREASE PAN
7	2	GREASE TRAY BRACKET
8	1	ELEMENT TRAY BOTTOM
9	8	ELEMENT TRAY SUPPORT PIN
10	2	BRACKET, F/ WARMING RACK
11	1	WARMING RACK
12	4	COOKING GRATE
13	2	HEATING ELEMENT
14	2	ELEMENT TRAY
15	2	GREASE TENT
16	1	GROMMET, SMOKE SHOT
17	1	FIREBOX FRAME
18	1	GROMMET, POWER CORD
19	2	MEAT PROBE
20	1	CONTROL PANEL HOUSING
21	1	OUTSIDE MEAT PROBE HOLDER
22	1	CONTROL MODULE
23	1	CONTROL KNOB
24	1	PROBE JACK, SET OF 2 (RED)
25	1	CONTROL MODULE PANEL
26	1	PROBE JACK, SET OF 2 (WHITE)
27	2	LEG CAP, REAR
28	2	LEG CAP, FRONT
29	1	RIGHT FRONT LEG (#3)
30	1	RIGHT REAR LEG (#4)
31	1	LEFT FRONT LEG (#1)
32	1	LEFT REAR LEG (#2)
33	1	CORD WRAP
34	1	TEMPERATURE SENSOR (RED)
35	1	TEMPERATURE SENSOR (WHITE)

Key	Qty	Description
36	1	FRONT BRACE
37	1	REAR BRACE
38	1	SHELF GROMMET (SET OF 2)
39	1	LEFT SIDE SHELF
40	1	RIGHT SIDE SHELF
41	1	DRAWER
42	1	TRAY, PERFORATED
43	1	MIDDLE CART SHELF
44	2	END CAP, F/ SIDE SHELF
45	1	BOTTOM SHELF
46	2	SLIDE RAIL BRACKET
47	2	SLIDE RAIL
48	1	TRAY, SOLID
49	1	WHEEL AXLE (SET OF 2)
50	2	WHEEL
51	2	CASTER, LOCKING
52	2	SIDE CART BRACE
53	1	POWER CORD REPLACE-MENT
54	1	POWER BOX MODULE
55	1	MAIN HARNESS
56	1	HEATING ELEMENT WIRE HARNESS/L
57	1	HEATING ELEMENT WIRE HARNESS/N
58	1	BRUSH
59	1	SCREWDRIVER
60*	6	PANEL CLIP
61 *	2	SIDE CART PANEL
62*	1	REAR CART PANEL
63 *	1	SPRING PIN, F/ DOOR
64 *	1	FIXED PIN, F/ DOOR
65*	1	HANDLE F/ DOOR
66*	1	MAGNET ASSEMBLY
67 *	1	DOOR, NO HANDLE
68	1	DRAWER LINER
69	8	SHELF HARDWARE

* INCLUDED WITH OPTIONAL CABINET KIT (SOLD SEPARATELY)


REPLACEMENT PARTS DIAGRAM




* INCLUDED WITH OPTIONAL CABINET KIT (SOLD SEPARATELY)


ASSEMBLY


1







2






3






4










ASSEMBLY


5







6







7





1st
3rd
2nd
Tighten all the screws.


ALIGN FIT WELL
GAP
OVERLAP

8






Set aside for later step


Push the slide rail to the end, exposing the screw hole.


Gx6




9


Gx4






10






11




Hx4




Steps 12-16 apply only if you purchased the optional cabinet kit (sold separately).


12

Kx1




13






14




15


Lx2




16



17





18




19

Jx4







20




21




1ST




2ND




22



23



24



TROUBLESHOOTING

Problem	Possible Cause	Prevention/Solution
Grill does not get to temperature	Setpoint changed	• Check if the setpoint has been lowered.
	Lid Left Open or opened frequently	• Leaving the grill lid open will prolong the heat-up process. When possible, keep lid closed while cooking.

	Temperature Sensor Defect	• If the temperature does not rise, check wire connections:
		  • Turn off and unplug grill.
		  • Remove control panel and ensure all wires are firmly connected - Reassemble the control panel and assess the temperature probe with the same method.
		• If temperature still does not rise, your temperature sensor may need to be replaced
		• **Please call our Current Backyard VIP Concierge Team at 1-866-Current for assistance.**

Food probe temperature does not show up in display or shows unreasonable value	Not fully seated/plugged in	• Push probe plug all the way into probe jack.
	Food probe damaged	• Plug probe into another probe jack and observe reading. If no display or an unreasonable value is shown, replace food probe. If temperature display is now active and at a reasonable value, try original jack once more. If display is still bad, the probe jack may need to be replaced. • **Please call our Current Backyard VIP Concierge Team at 1-866-Current for assistance.**
	Contamination in the food probe jack	• Inspect the food probe jacks that do not report a temperature with a flashlight to find any debris. If there is debris, ensure the grill is unpowered and then remove debris carefully.Check that the food probe connector is clean and dry. Insert the food probe into an adjacent jack to inspect for a reading. If there is no temperature displayed in the controller for any of the jacks, then the food probe is damaged.
	Food probe is not properly inserted in food	• Tip of probe should be inserted into thickest part of the food being measured. Food probe should not be in direct contact with any bone since direct contact will prevent an accurate reading. Food probe should not be in contact with grill surface.
Product won't connect to Bluetooth	Product is too far away from phone	• Complete pairing process with device within 1,5m (5 ft) of phone.
	Phone Bluetooth turned off or on Airplane Mode	• In your mobile device settings, make sure Bluetooth is turned on and airplane mode is disabled. 1. For Android devices, make sure that location services are turned on and that the application is permitted to use location services. This will enable Bluetooth to be used in the application. 2. For iPhone devices, check that Bluetooth is enabled for the application in the operating system settings.
	Product is already paired to another phone	• Use the original mobile device paired to the product or reset the grill's connections. If resetting the grill connection, first remove the product from the mobile device Bluetooth settings. Alternatively, turn off bluetooth on the previous mobile device while performing the pairing process. • To reset grill connection, press and hold the control knob for 10 seconds. A beep will sound indicating reset is complete. Now go through the paring process for Bluetooth on the device.
	Product is already paired to the same phone	• Turn the product off and close the application. Turn product back on and re-open the application. If product is still not connected by Bluetooth, remove the product from the mobile phone operating system Bluetooth device settings. On the grill, press and hold the control knob until it beeps to clear the grill's Bluetooth settings and restart the pairing process.

TROUBLESHOOTING

Problem	Possible Cause	Prevention/Solution
Product won't connect to WiFi	Incorrect router password	• Check password and try wifi connection process again.
	No internet	• Verify internet access on other devices.If other devices have internet: - Unplug grill for 30 seconds and plug back in. Check for connection. - Unplug router for 30 seconds and plug back in. Check for connection. Perform WiFi setup in the application again - if the WiFi network does not appear in the scan list, the product may be too far from the router.
	Router is too far away from grill	• Perform WiFi setup in the application again - if the WiFi network does not appear in the scan list, the product may be too far from the router. With a mobile device in the area where the grill is located, check that there is internet access.
	Obstacles between router and grill	• Position grill such that the number of walls and objects between the grill and the router is minimized.
	No 2.4GHz wifi	• Grill only supports 2.4G WiFi networks. An alternate router is required.
Controller Failure • No power to the control console. • Grill starts ok but control screen goes blank, grill stops working.	The unit is not plugged in.	• Check to be sure if cord is properly plugged into outlet. Plug into outlet and reassess.
	The power circuit fuse has tripped.	• Check if GFCI outlet or breaker has been tripped and reset circuit.
	• A power cord malfunction or failure. • Controller malfunction.	• Unplug the grill from power. Remove the Control Panel and ensure all wires are not damaged and are firmly connected, particularly the power cord. If wires are damaged, replace appropriate components and reassess. If wires are not damaged and connections are confirmed, please contact our Current Backyard VIP Concierge Team at 1-866-Current for further assistance.
GFCI Issues • No power to the control console. • Grill starts ok but control screen goes blank, grill stops working. • GFCI reset button pops out on outlet.	• Faulty GFCI outlet. • Moisture inside outlet. • Outlet not on a dedicated circuit. • Amp draw on outlet rated lower than 15 amps. • Circuit breaker issues."	• Unplug everything from the outlet. • Press the reset button on the outlet and ensure the test button returns to normal position. • Plug in and turn on grill for around 10 minutes, watch for GFCI tripping. • If GFCI did trip during the 10-minute period verify the amp draw of the GFCI. If Outlet is not 15-amp or higher, replace the Outlet. • If GFCI did not trip during the 10-minute period, and if you are using a second appliance on the same outlet, re-plug in and turn on the original second appliance. • If GFCI trips with the second appliance on, there may be an issue with the second appliance. • Plug a different appliance into the same outlet and turn the appliance on. • If tripping occurs with the different appliance an electrician may be required.Unplug everything from the outlet.

LIMITED WARRANTY

This warranty only applies to units purchased from an authorized retailer. Manufacturer warrants to the original consumer-purchaser only that this product shall be free from defects in workmanship and materials after correct assembly and under normal and reasonable home use for the periods indicated below beginning on the date of purchase*. The manufacturer reserves the right to require that defective parts be returned, postage and or freight pre-paid by the consumer for review and examination. **Visit currentbackyard.com for policies regarding damage during shipping.**

SCOPE OF COVERAGE	PERIOD OF COVERAGE with Registration	PERIOD OF COVERAGE *WITHOUT* Registration	TYPE OF FAILURE COVERAGE
Grill Lid and Grates	10 years from date of purchase*	5 years from date of purchase*	PERFORATION, MANUFACTURING, AND MATERIAL DEFECTS ONLY
Electronics	2 years from date of purchase*	1 years from date of purchase*	
All Other Parts	5 years from date of purchase*	3 years from date of purchase*	

*Note: A dated sales receipt WILL be required for warranty service.

To obtain extended warranty coverage, you must register your product within 60 days of purchase.

This limited warranty is applicable in the United States only, is only available to the original owner of the product and is not transferable. **Manufacturer requires proof of your date of purchase. Therefore, you should retain your sales slip or invoice.** Registering your product is not a substitute for proof of purchase and the manufacturer is not responsible for or required to retain proof of purchase records. This limited warranty applies to the functionality of the product ONLY and does not cover cosmetic issues such as scratches, dents, corrosions or discoloring by heat, abrasive and chemical cleaners or any tools used in the assembly or installation of the appliance, surface rust, or the discoloration of stainless steel surfaces. Paint is not warranted and will require touch up. RUST is not considered a manufacturing or materials defect.

This limited warranty will not reimburse you for the cost of any inconvenience, food, personal injury or property damage.

ITEMS MANUFACTURER WILL NOT PAY FOR:

1. Expedited shipping cost for warranty and replacement parts.
2. Service calls to your home.
3. Repairs when your product is used for other than normal, single-family household or residential use.
4. Damage, failures, or operating difficulties resulting from accident, alteration, careless handling, misuse, abuse, fire, flood, acts of God, improper installation or maintenance, installation not in accordance with electrical or plumbing codes, or use of products not approved by the manufacturer.
5. Any food loss due to product failures or operating difficulties.
6. Replacement parts or repair labor costs for units operated outside the United States.
7. Pickup and delivery of your product.
8. Repairs to parts or systems resulting from unauthorized modifications made to the product.
9. The removal and/or reinstallation of your product.

DISCLAIMER OF IMPLIED WARRANTIES and LIMITATION OF REMEDIES

Repair or replacement of defective parts is your exclusive remedy under the terms of this limited warranty. In the event of parts availability issues, the manufacturer reserves the right to substitute like or similar parts that are equally functional. Manufacturer will not be responsible for any consequential or incidental damages arising from the breach of either this limited warranty or any applicable implied warranty, or for failure or damage resulting from acts of God, improper care and maintenance, grease fire, accident, alteration,replacement of parts by anyone other than Manufacturer, misuse, transportation, commercial use, abuse, hostile environments (inclement weather, acts of nature, animal tampering), improper installation or installation not in accordance with local codes or printed manufacturer instructions.

THIS LIMITED WARRANTY IS THE SOLE EXPRESS WARRANTY GIVEN BY THE MANUFACTURER. NO PRODUCT PERFORMANCE SPECIFICATION OR DESCRIPTION WHEREVER APPEARING IS WARRANTED BY MANUFACTURER EXCEPT TO THE EXTENT SET FORTH IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTY PROTECTION ARISING UNDER THE LAWS OF ANY STATE, INCLUDING IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE, IS HEREBY LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY.

Neither dealers nor the retail establishment selling this product has any authority to make any additional warranties or to promise remedies in addition to or inconsistent with those stated above. Manufacturer's maximum liability, in any event, shall not exceed the purchase price of the product paid by the original consumer. NOTE: Some states do not allow an exclusion or limitation of incidental or consequential damages, so some of the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights as set forth herein. You may also have other rights which vary from state to state. In the state of California only, if refinishing or replacement of the product is not commercially practicable, the retailer selling this product or the Manufacturer will refund the purchase price paid for the product, less the amount directly attributable to use by the original consumer-purchaser prior to discovery of the nonconformity. In addition, in the state of California only, you may take the product to the retail establishment selling this product in order to obtain performance under this limited warranty. If you wish to obtain performance of any obligation under this limited warranty, you should write to:

Consumer Relations
P. O. Box 1240
Columbus, GA 31902-1240

Consumer returns will not be accepted unless a valid Return Authorization is first acquired. Authorized returns are clearly marked on the outside of the package with an RA number and the package is shipped freight/postage pre-paid. Consumer returns that do not meet these standards will be refused.

NOTES

PRODUCT REGISTRATION

Register your product online at https://currentbackyard.com/pages/product-registration.
Find your model number on the product rating label located under the control panel of the grill.

For product support, contact the Current Backyard VIP Concierge Team at 1-866-Current, or support@currentbackyard.com

26554001
26554002
26554003

CURRENT

22
PAP

©2026 CURRENT, LLC. COLUMBUS, GA 31904

Printed in China
The product associated with this guide was manufactured in China

AW# CUR-25-89